



MFC 400 Technical Datasheet

Signal converter for mass flowmeters

- High performance signal converter for all applications
- Stable in multi-phase applications due to Entrained Gas Management (EGM®)
- High developed diagnostic functions acc. to NAMUR NE 107



The documentation is only complete when used in combination with the relevant documentation for the flow sensor.

| | |
|--|----|
| 1 Product features | 3 |
| 1.1 The high performance signal converter for all applications | 3 |
| 1.2 Options and variants | 5 |
| 1.3 Signal converter/flow sensor combination possibilities | 6 |
| 1.4 Measuring principle..... | 6 |
| 2 Technical data | 7 |
| 2.1 Technical data..... | 7 |
| 2.2 Dimensions and weights | 18 |
| 2.2.1 Housing | 18 |
| 2.2.2 Mounting plate, field housing | 18 |
| 3 Installation | 19 |
| 3.1 Intended use | 19 |
| 3.2 Installation specifications | 19 |
| 3.3 Mounting of the compact version..... | 19 |
| 3.4 Mounting the field housing, remote version | 20 |
| 3.4.1 Pipe mounting | 20 |
| 3.4.2 Wall mounting | 21 |
| 4 Electrical connections | 22 |
| 4.1 Safety instructions..... | 22 |
| 4.2 Connection diagram | 22 |
| 4.3 Grounding the flow sensor | 23 |
| 4.4 Connecting power – all housing variants..... | 24 |
| 4.5 Inputs and outputs, overview | 25 |
| 4.5.1 Combinations of the inputs/outputs (I/Os) | 25 |
| 4.5.2 Description of the CG number | 26 |
| 4.5.3 Fixed, non-alterable input/output versions..... | 27 |
| 4.5.4 Alterable input/output versions..... | 29 |
| 5 Notes | 30 |

1.1 The high performance signal converter for all applications

The **MFC 400** Coriolis mass flow signal converter will provide the highest performance possible across a wide range of applications. For the measurement of liquids or gases, cryogenic to high temperature fluids, single or multi-phase fluids and advanced digital signal processing techniques is used to give stable and accurate measurements of mass flow, density and temperature.

Conforming to the NAMUR standard NE 107 for status and error handling, the MFC 400 features enhanced meter diagnostics. This provides extensive self-checking of internal circuits and information regarding the health of the measuring sensor, but just as importantly, vital information about the process and process conditions.



(signal converter in field housing)

- ① Communication with any third party system possible via Foundation Fieldbus, Profibus PA/DP or Modbus
- ② Intuitive navigation and a wide variety of languages integrated as standard for ease of operation
- ③ Supply voltage: 100...230 VAC (standard) and 24 VDC or 24 VAC/DC (optional)

Highlights

- High performance signal converter with multiple output options
- Advanced diagnostic functions acc. to NE 107
- With Entrained Gas Management (EGM™) – the new standard for entrained gas immunity
- Excellent long-term stability
- Easy to install and program due to improved user interface
- Optical and mechanical keys for ease of use
- Redundant data storage in signal converter housing
- Real time clock for logging events
- HART® 7

Industries

- Water & Wastewater
- Chemicals
- Power plants
- Food & Beverage
- Machinery
- Oil & Gas
- Petrochemical
- Pulp & Paper
- Pharmaceutical
- Marine

Applications

- Liquids and gases
- Liquids with gas entrainment
- Slurries and viscous products
- Concentration measurement for quality control
- Measurement of volume flow
- Measurement of density and reference density
- Custody transfer loading/unloading
- Custody transfer measurements

1.2 Options and variants

Compact design for standard applications



(Example: OPTIMASS 6400 – compact)



(Example: OPTIMASS 2400 – compact)

The MFC 400 mass flow signal converter is available in different variants and offers superior performance in any conceivable application. From process control in chemistry, to density and concentration measurements in the food and beverage industry, to custody transfer filling and transport measurements for oil and gas right down to conveyor systems in the pulp and paper industry.

Coriolis mass flow measuring systems measure the mass and volume flow, the density and the temperature of liquids and gases. In addition, the concentration in mixtures and slurries can also be determined.

Thanks to Entrained Gas Management (EGM™) the MFC 400 systems offer high performance with air entrainment, delivering continuous measurement even with 0...100% gas entrainment.

For standard applications the compact housing is mounted directly on the measuring sensor. In the unlikely event of a failure, the electronics can be easily exchanged and reconfigured using a backup data set that is stored in the housing.

Remote field housing version



(signal converter in field housing)

The signal converter in the robust field housing is generally used when it is difficult to access the measuring point or when ambient conditions do not allow the use of the compact version.

1.3 Signal converter/flow sensor combination possibilities

| Flow sensor | Flow sensor + signal converter MFC 400 | |
|---------------|--|----------------------|
| | Compact | Remote field housing |
| OPTIMASS 1000 | OPTIMASS 1400 C | OPTIMASS 1400 F |
| OPTIMASS 2000 | OPTIMASS 2400 C | OPTIMASS 2400 F |
| OPTIMASS 3000 | OPTIMASS 3400 C | OPTIMASS 3400 F |
| OPTIMASS 6000 | OPTIMASS 6400 C | OPTIMASS 6400 F |
| OPTIMASS 7000 | OPTIMASS 7400 C | OPTIMASS 7400 F |

1.4 Measuring principle

The signal converter has been designed to work with all the measuring tube designs used in the mass flowmeters. For information regarding the measuring principle for a specific measuring tube design, please refer to the technical documentation of the relevant flow sensor.

2.1 Technical data

- The following data is provided for general applications. If you require data that is more relevant to your specific application, please contact us or your local sales office.
- Additional information (certificates, special tools, software,...) and complete product documentation can be downloaded free of charge from the website (Downloadcenter).

Measuring system

| | |
|---------------------|---|
| Measuring principle | Coriolis principle |
| Application range | Measurement of mass flow, density, temperature, volume flow, flow velocity, concentration |

Design

| | |
|------------------------------------|--|
| Modular construction | The measuring system consists of a flow sensor and a signal converter. |
| Flow sensor | |
| OPTIMASS 1000 | DN15...50 / ½...2" |
| OPTIMASS 2000 | DN100...250 / 4...10" |
| OPTIMASS 3000 | DN01...04 / 1/25...4/25" |
| OPTIMASS 6000 | DN08...250 / 3/8...10" |
| OPTIMASS 7000 | DN06...80 / ¼...3" |
| | All flow sensors are also available in an Ex version. |
| Signal converter | |
| Compact version (C) | OPTIMASS x400 C (x = 1, 2, 3, 6 or 7) |
| Field housing (F) - remote version | MFC 400 F |
| | Compact and field housing versions are also available in an Ex version. |
| Options | |
| Outputs / inputs | Current output (incl. HART®), pulse output, frequency output, and/or status output, limit switch and/or control input (depending on the I/O version) |
| Totaliser | 2 (optional 3) internal totalisers with a max. of 8 counter places (e.g. for counting volume and/or mass units) |
| Verification | Integrated verification, diagnostic functions: measuring device, process, measured value, stabilisation |
| Concentration measurement | Universal concentration measurement, °Brix, °Baume, °Plato, alcohol concentration, NaOH and API density |
| Communication interfaces | Foundation Fieldbus, Profibus PA and DP, Modbus, HART® |

| Display and user interface | |
|--|--|
| Graphic display | LC display, backlit white. |
| | Size: 128 x 64 pixels, corresponds to 59 x 31 mm = 2.32" x 1.22" |
| | Display turnable in 90° steps. |
| | Ambient temperatures below -25°C / -13°F may affect the readability of the display. |
| Operating elements | 4 push buttons/optical keys for operator control of the signal converter without opening the housing. |
| | Infrared interface for reading and writing all parameters with IR interface (option) without opening the housing. |
| Remote operation | PACTware™ (incl. Device Type Manager (DTM)) |
| | HART® Hand Held Communicator from Emerson Process |
| | AMS® from Emerson Process |
| | PDM® from Siemens |
| | All DTMs and drivers are available free of charge from the manufacturer's website. |
| Display functions | |
| Operating menu | Setting the parameters using 2 measuring pages, 1 status page, 1 graphic page (measured values and graphics are freely adjustable) |
| Language display texts (as language package) | Standard: English, French, German, Dutch, Portuguese, Swedish, Spanish, Italian |
| | Eastern Europe (in preparation): English, Slovenian, Czech, Hungarian |
| | Northern Europe: English, Danish, Polish |
| | Southern Europe: English, Turkish |
| | China (in preparation): English, Chinese |
| | Russia: English, Russian |
| Measurement functions | Units: Metric, British and US units selectable as desired from lists for volume/mass flow and counting, velocity, temperature, pressure |
| | Measured values: Mass flow, total mass, temperature, density, volume flow, total volume, velocity, flow direction (not displayed unit – but available via outputs), BRIX, Baume, NaOH, Plato, API, mass concentration, volume concentration |
| Diagnostic functions | Standards: VDI / NAMUR / WIB 2650 and NE 107 |
| | Status messages: Output of status messages optional via display, current and/or status output, HART® or bus interface |
| | Sensor diagnosis: Sensor values, drive level, measuring tube frequency, 2 phase signal, drive coil impedance, insulation fault, circuit interruption, exceeding the maximum flow, process temperature |
| | Self-diagnosing sensor electronics: Electronics temperature, input gains, driver amplifier |
| | Signal converter and inputs/outputs: Data bus monitoring, current output connections, electronics temperature, voltage drop, parameter and data integrity |

Measuring accuracy

| | |
|----------------------------|--|
| Reference conditions | Medium: water |
| | Temperature: +20°C / +68°F |
| | Pressure: 1 bar / 14.5 psi |
| Maximum measuring error | Refer to technical data for the flow sensor. |
| Current output electronics | ±5 µA |

Operating conditions

| | |
|---|---|
| Temperature | |
| Process temperature | Refer to technical data for the flow sensor. |
| Ambient temperature | Depending on the version and combination of outputs. |
| | It is a good idea to protect the signal converter from external heat sources such as direct sunlight as higher temperatures reduce the life cycle of all electronic components. |
| | -40...+65°C / -40...+149°F |
| | Stainless steel housing: -40...+60°C / -40...+140°F |
| | Ambient temperatures below -25°C / -13°F may affect the readability of the display. |
| Storage temperature | -50...+70°C / -58...+158°F |
| Pressure | |
| Medium | Refer to technical data for the flow sensor. |
| Ambient pressure | Atmospheric |
| Chemical properties | |
| State of aggregation | Liquids, gases and slurries |
| Flow rate | Refer to technical data for the flow sensor. |
| Other conditions | |
| Ingress protection acc. to IEC 529 / EN 60529 | IP66/67 (acc. to NEMA 4/4X) |

Installation conditions

| | |
|------------------------|---|
| Installation | For detailed information, refer to chapter "Installation conditions". |
| Dimensions and weights | For detailed information refer to chapter "Dimensions and weights". |

Materials

| | |
|--------------------------|---|
| Signal converter housing | Standard: die-cast aluminium (polyurethane coated) |
| | Option: stainless steel 316 (1.4408) |
| Flow sensor | For housing material, process connections, measuring tubes, accessories and gaskets, refer to technical data for the flow sensor. |

Electrical connection

| | |
|-------------------|--|
| General | Electrical connection is carried out in conformity with the VDE 0100 directive "Regulations for electrical power installations with line voltages up to 1000 V" or equivalent national specifications. |
| Power supply | Standard: 100...230 VAC (-15% / +10%), 50/60 Hz |
| | Option 1: 24 VDC (-55% / +30%) |
| | Option 2: 24 VAC/DC (AC: -15% / +10%, 50/60 Hz; DC: -25% / +30%) |
| Power consumption | AC: 22 VA |
| | DC: 12 W |
| Signal cable | Only for remote versions. |
| | 10 core shielded cable. Detailed specifications are available on request. |
| | Length: max. 20 m / 65.6 ft |
| Cable entries | Standard: M20.5 (8...12 mm) |
| | Option: ½ NPT, PF ½ |

Inputs and outputs

| | | | |
|------------------------------|--|--------------|--|
| General | All outputs are electrically isolated from each other and from all other circuits. | | |
| | All operating data and output values can be adjusted. | | |
| Description of abbreviations | U _{ext} = external voltage; R _L = load + resistance; U ₀ = terminal voltage; I _{nom} = nominal current Safety limit values (Ex i): U _i = max. input voltage; I _i = max. input current; P _i = max. input power rating; C _i = max. input capacity; L _i = max. input inductivity | | |
| Current output | | | |
| Output data | Volume flow, mass flow, temperature, density, flow velocity, diagnostic value, 2-phase signal | | |
| | Concentration and concentration flow are also possible with available concentration measurement (optional). | | |
| Temperature coefficient | Typically ±30 ppm/K | | |
| Settings | Without HART® | | |
| | Q = 0%: 0...20 mA; Q = 100%: 10...20 mA | | |
| | Error identification: selectable 3...22 mA | | |
| | With HART® | | |
| | Q = 0%: 4...20 mA; Q = 100%: 10...20 mA | | |
| | Error identification: selectable 3...22 mA | | |
| Operating data | Basic I/Os | Modular I/Os | Ex i |
| Active | U _{int, nom} = 24 VDC I ≤ 22 mA R _L ≤ 1 kΩ | | U _{int, nom} = 20 VDC I ≤ 22 mA R _L ≤ 450 Ω |
| | | | U ₀ = 21 V I ₀ = 90 mA P ₀ = 0.5 W C ₀ = 90 nF / L ₀ = 2 mH C ₀ = 110 nF / L ₀ = 0.5 mH |
| Passive | U _{ext} ≤ 32 VDC I ≤ 22 mA U ₀ ≥ 1.8 V R _L ≤ (U _{ext} - U ₀) / I _{max} | | U _{ext} ≤ 32 VDC I ≤ 22 mA U ₀ ≥ 4 V R _L ≤ (U _{ext} - U ₀) / I _{max} |
| | | | U _i = 30 V I _i = 100 mA P _i = 1 W C _i = 10 nF L _i ~ 0 mH |

| HART® | | | |
|--|--|--|------|
| Description | HART® protocol via active and passive current output | | |
| | HART® version: V7 | | |
| | Universal HART® parameter: completely integrated | | |
| Load | ≥ 250 Ω at HART® test point; Note maximum load for current output! | | |
| Multidrop operation | Yes, current output = 10%, e.g. 4 mA | | |
| | Multi-drop address adjustable in operation menu 0...63 | | |
| Device drivers | Available for FC 375/475, AMS, PDM, FDT/DTM | | |
| Registration (HART Communication Foundation) | Yes | | |
| Pulse output or frequency output | | | |
| Output data | Pulse output: volume flow, mass flow, mass or volume of dissolved substance during activated concentration measurement | | |
| | Frequency output: flow velocity, mass flow, temperature, density, diagnostic value Optional: concentration, flow of the dissolved substance | | |
| Function | Can be set as a pulse output or frequency output | | |
| Pulse rate/frequency | 0.01...10000 pulses/s or Hz | | |
| Settings | Mass or volume per pulse or max. frequency for 100% flow | | |
| | Pulse width: adjustable as automatic, symmetric or fixed (0.05...2000 ms) | | |
| Operating data | Basic I/Os | Modular I/Os | Ex i |
| Active | - | U _{nom} = 24 VDC | - |
| | | f _{max} in operating menu set to f _{max} ≤ 100 Hz: I ≤ 20 mA open: I ≤ 0.05 mA closed: U _{0, nom} = 24 V at I = 20 mA | |
| | | f _{max} in operating menu set to 100 Hz < f _{max} ≤ 10 kHz: I ≤ 20 mA open: I ≤ 0.05 mA closed: U _{0, nom} = 22.5 V at I = 1 mA U _{0, nom} = 21.5 V at I = 10 mA U _{0, nom} = 19 V at I = 20 mA | |

| | | | |
|------------------|--|--|---|
| Passive | U _{ext} ≤ 32 VDC | | - |
| | f _{max} in operating menu set to f _{max} ≤ 100 Hz: I ≤ 100 mA open: I ≤ 0.05 mA at U _{ext} = 32 VDC closed: U _{0, max} = 0.2 V at I ≤ 10 mA U _{0, max} = 2 V at I ≤ 100 mA | | |
| | f _{max} in operating menu set to 100 Hz < f _{max} ≤ 10 kHz: I ≤ 20 mA open: I ≤ 0.05 mA at U _{ext} = 32 VDC closed: U _{0, max} = 1.5 V at I ≤ 1 mA U _{0, max} = 2.5 V at I ≤ 10 mA U _{0, max} = 5.0 V at I ≤ 20 mA | | |
| NAMUR | - | Passive to EN 60947-5-6 | Passive to EN 60947-5-6 |
| | | open: I _{nom} = 0.6 mA closed: I _{nom} = 3.8 mA | open: I _{nom} = 0.43 mA closed: I _{nom} = 4.5 mA |
| | | | U _i = 30 V I _i = 100 mA P _i = 1 W C _i = 10 nF L _i ~ 0 mH |
| Low flow cut off | | | |
| Function | Switching point and hysteresis separately adjustable for each output, counter and the display | | |
| Switching point | Set in increments of 0.1%. | | |
| | 0...20% (current output, frequency output) | | |
| Hysteresis | Set in increments of 0.1%. | | |
| | 0...5% (current output, frequency output) | | |
| Time constant | | | |
| Function | The time constant corresponds to the elapsed time until 67% of the end value has been reached according to a step function. | | |
| Settings | Set in increments of 0.1 seconds. | | |
| | 0...100 seconds | | |

| Status output / limit switch | | | |
|------------------------------|---|--|--|
| Function and settings | Adjustable as automatic measuring range conversion, display of flow direction, overflow, error or switching point. | | |
| | Valve control with activated dosing function | | |
| | Status and/or control: ON or OFF | | |
| Operating data | Basic I/Os | Modular I/Os | Ex i |
| Active | - | $U_{\text{int}} = 24 \text{ VDC}$ $I \leq 20 \text{ mA}$ open: $I \leq 0.05 \text{ mA}$ closed: $U_{0, \text{nom}} = 24 \text{ V}$ at $I = 20 \text{ mA}$ | - |
| Passive | $U_{\text{ext}} \leq 32 \text{ VDC}$ $I \leq 100 \text{ mA}$ open: $I \leq 0.05 \text{ mA}$ at $U_{\text{ext}} = 32 \text{ VDC}$ closed: $U_{0, \text{max}} = 0.2 \text{ V}$ at $I \leq 10 \text{ mA}$ $U_{0, \text{max}} = 2 \text{ V}$ at $I \leq 100 \text{ mA}$ | $U_{\text{ext}} \leq 32 \text{ VDC}$ $I \leq 100 \text{ mA}$ $R_{L, \text{max}} = 47 \text{ k}\Omega$ $R_{L, \text{min}} = (U_{\text{ext}} - U_0) / I_{\text{max}}$ open: $I \leq 0.05 \text{ mA}$ at $U_{\text{ext}} = 32 \text{ VDC}$ closed: $U_{0, \text{max}} = 0.2 \text{ V}$ at $I \leq 10 \text{ mA}$ $U_{0, \text{max}} = 2 \text{ V}$ at $I \leq 100 \text{ mA}$ | - |
| NAMUR | - | Passive to EN 60947-5-6 open: $I_{\text{nom}} = 0.6 \text{ mA}$ closed: $I_{\text{nom}} = 3.8 \text{ mA}$ | Passive to EN 60947-5-6 open: $I_{\text{nom}} = 0.43 \text{ mA}$ closed: $I_{\text{nom}} = 4.5 \text{ mA}$ $U_i = 30 \text{ V}$ $I_i = 100 \text{ mA}$ $P_i = 1 \text{ W}$ $C_i = 10 \text{ nF}$ $L_i = 0 \text{ mH}$ |

| Control input | | | |
|----------------|--|---|---|
| Function | Hold value of the outputs (e.g. for cleaning work), set value of the outputs to "zero", counter and error reset, stop counter, range conversion, zero calibration | | |
| | Start of dosing when dosing function is activated. | | |
| Operating data | Basic I/Os | Modular I/Os | Ex i |
| Active | - | $U_{\text{int}} = 24 \text{ VDC}$ Ext. contact open: $U_{0, \text{nom}} = 22 \text{ V}$ Ext. contact closed: $I_{\text{nom}} = 4 \text{ mA}$ Contact open (Off): $U_0 \geq 12 \text{ V}$ with $I_{\text{nom}} = 1.9 \text{ mA}$ Contact closed (On): $U_0 \leq 10 \text{ V}$ with $I_{\text{nom}} = 1.9 \text{ mA}$ | - |
| Passive | $8 \text{ V} \leq U_{\text{ext}} \leq 32 \text{ VDC}$ $I_{\text{max}} = 6.5 \text{ mA}$ at $U_{\text{ext}} \leq 24 \text{ VDC}$ $I_{\text{max}} = 8.2 \text{ mA}$ at $U_{\text{ext}} \leq 32 \text{ VDC}$ Contact closed (On): $U_0 \geq 8 \text{ V}$ with $I_{\text{nom}} = 2.8 \text{ mA}$ Contact open (Off): $U_0 \leq 2.5 \text{ V}$ with $I_{\text{nom}} = 0.4 \text{ mA}$ | $3 \text{ V} \leq U_{\text{ext}} \leq 32 \text{ VDC}$ $I_{\text{max}} = 9.5 \text{ mA}$ at $U_{\text{ext}} \leq 24 \text{ V}$ $I_{\text{max}} = 9.5 \text{ mA}$ at $U_{\text{ext}} \leq 32 \text{ V}$ Contact closed (On): $U_0 \geq 3 \text{ V}$ with $I_{\text{nom}} = 1.9 \text{ mA}$ Contact open (Off): $U_0 \leq 2.5 \text{ V}$ with $I_{\text{nom}} = 1.9 \text{ mA}$ | $U_{\text{ext}} \leq 32 \text{ VDC}$ $I \leq 6 \text{ mA}$ at $U_{\text{ext}} = 24 \text{ V}$ $I \leq 6.6 \text{ mA}$ at $U_{\text{ext}} = 32 \text{ V}$ On: $U_0 \geq 5.5 \text{ V}$ or $I \geq 4 \text{ mA}$ Off: $U_0 \leq 3.5 \text{ V}$ or $I \leq 0.5 \text{ mA}$ |
| | | | $U_i = 30 \text{ V}$ $I_i = 100 \text{ mA}$ $P_i = 1 \text{ W}$ $C_i = 10 \text{ nF}$ $L_i = 0 \text{ mH}$ |
| NAMUR | - | Active to EN 60947-5-6 Terminals open: $U_{0, \text{nom}} = 8.7 \text{ V}$ Contact closed (On): $U_{0, \text{nom}} = 6.3 \text{ V}$ with $I_{\text{nom}} > 1.9 \text{ mA}$ Contact open (Off): $U_{0, \text{nom}} = 6.3 \text{ V}$ with $I_{\text{nom}} < 1.9 \text{ mA}$ Detection of cable break: $U_0 \geq 8.1 \text{ V}$ with $I \leq 0.1 \text{ mA}$ Detection of cable short circuit: $U_0 \leq 1.2 \text{ V}$ with $I \geq 6.7 \text{ mA}$ | - |

| | |
|----------------------------|---|
| PROFIBUS DP | |
| Description | Galvanically isolated acc. to IEC 61158 |
| | Profile version: 3.02 |
| | Automatic data transmission rate recognition (max. 12 MBaud) |
| | Bus address adjustable via local display at the measuring device |
| Function blocks | 8 x analogue input, 3 x totaliser |
| Output data | Mass flow, volume flow, mass counter 1 + 2, volume counter, product temperature, several concentration measurements and diagnostic data |
| PROFIBUS PA | |
| Description | Galvanically isolated acc. to IEC 61158 |
| | Profile version: 3.02 |
| | Current consumption: 10.5 mA |
| | Permissible bus voltage: 9...32 V; in Ex application: 9...24 V |
| | Bus interface with integrated reverse polarity protection |
| | Typical error current FDE (Fault Disconnection Electronic): 4.3 mA |
| | Bus address adjustable via local display at the measuring device |
| Function blocks | 8 x analogue input, 3 x totaliser |
| Output data | Mass flow, volume flow, mass counter 1 + 2, volume counter, product temperature, several concentration measurements and diagnostic data |
| FOUNDATION Fieldbus | |
| Description | Galvanically isolated acc. to IEC 61158 |
| | Current consumption: 10.5 mA |
| | Permissible bus voltage: 9...32 V; in Ex application: 9...24 V |
| | Bus interface with integrated reverse polarity protection |
| | Link Master function (LM) supported |
| | Tested with Interoperable Test Kit (ITK) version 6.01 |
| Function blocks | 6 x analogue input, 2 x integrator, 1 x PID |
| Output data | Mass flow, volume flow, density, temperature of tube, several concentration measurements and diagnostic data |
| Modbus | |
| Description | Modbus RTU, Master/Slave, RS485 |
| Address range | 1...247 |
| Supported function codes | 01, 03, 04, 05, 08, 16, 43 |
| Supported Baudrate | 1200, 2400, 3600, 4800, 9600, 19200, 38400, 57600, 115200 Baud |

Approvals and certificates

| | |
|---------------------------------------|--|
| CE | The device fulfils the statutory requirements of the EC directives. The manufacturer certifies that these requirements have been met by applying the CE marking. |
| Non-Ex | Standard |
| Hazardous areas | |
| Option (C version only) | |
| ATEX | II 1/2 (1) G - Ex d ia [ia Ga] IIC T6...T1 Ga/Gb |
| | II 1/2 (1) G - Ex de ia [ia Ga] IIC T6...T1 Ga/Gb |
| | II 2 (1) G - Ex d ia [ia Ga] IIC T6...T1 Gb |
| | II 2 (1) G - Ex de ia [ia Ga] IIC T6...T1 Gb |
| | II 2 (1) D - Ex t [ia Da] IIIC Txxx°C Db |
| | II 1/2 G - Ex d ia IIC T6...T1 Ga/Gb; II 1/2 G - Ex de ia IIC T6...T1 Ga/Gb |
| | II 2 G - Ex d ia IIC T6...T1 Gb; II 2 G - Ex de ia IIC T6...T1 Gb |
| | II 2 D - Ex t IIIC Txxx°C Db |
| Option (F version only) | |
| ATEX | II 2 (1) G - Ex d [ia Ga] IIC T6 Gb |
| | II 2 (1) G - Ex de [ia Ga] IIC T6 Gb |
| | II 2 (1) D - Ex t [ia Da] IIIC T75°C Db |
| | II 2 G - Ex d [ia] IIC T6 Gb; II 2 G - Ex de [ia] IIC T6 Gb |
| | II 2 D - Ex t IIIC T75°C Db |
| NEPSI | Ex d ia [ia Ga] IIC T6...T1 Ga/Gb; Ex de ia [ia Ga] IIC T6...T1 Ga/Gb |
| Option | |
| FM / CSA | FM: Class I, Div 1 groups A, B, C, D CSA: Class I, Div 1 groups C, D |
| | Class II, Div 1 groups E, F, G |
| | Class III, Div 1 hazardous areas |
| | FM: Class I, Div 2 groups A, B, C, D CSA: Class I, Div 2 groups C, D |
| | Class II, Div 2 groups E, F, G |
| | Class III, Div 2 hazardous areas |
| IECEX | Ex zone 1 + 2 |
| Custody transfer | |
| Without | Standard |
| Option | Liquids other than water 2004/22/EC (MID MI005) acc. to OIML R 117-1 |
| | Gases 2004/22/EC (MID MI002) acc. to OIML R 137 |
| Other standards and approvals | |
| Shock and vibration resistance | IEC 68-2-3 |
| Electromagnetic compatibility (EMC) | 2004/108/EC in conjunction with EN 61326-1 (A1, A2) |
| European pressure equipment directive | PED 97/23/EC |
| NAMUR | NE 21, NE 43, NE 53, NE 107 |

2.2 Dimensions and weights

2.2.1 Housing





Figure 2-1: Dimensions for field housing (F) - remote version

| Dimensions [mm / inch] | | | | | Weight [kg / lb] |
|------------------------|------------|------------|---------------|-------------|------------------|
| a | b | c | g | h | |
| 202 / 7.75 | 120 / 4.75 | 155 / 6.10 | 295.8 / 11.60 | 277 / 10.90 | 5.7 / 12.60 |

2.2.2 Mounting plate, field housing



Dimensions in mm and inch

| | [mm] | [inch] |
|---|------|--------|
| a | 72 | 2.8 |
| b | 72 | 2.8 |
| c | Ø9 | Ø0.4 |

3.1 Intended use

The mass flowmeters are designed exclusively to directly measure mass flow rates, product density and temperature as well to indirectly measure parameters such as the total volume and concentration of dissolved substances as well as the volume flow rate.

For devices used in hazardous areas, additional safety notes apply; please refer to the Ex documentation.

If the device is not used according to the operating conditions (refer to chapter Technical data), the intended protection could be affected.

3.2 Installation specifications

The following precautions must be taken to ensure reliable installation.

- *Make sure that there is adequate space to the sides.*
- *Protect the signal converter from direct sunlight and install a sun shade if necessary.*
- *Signal converters installed in control cabinets require adequate cooling, e.g. by fan or heat exchanger.*
- *Do not expose the signal converter to intense vibrations. The measuring devices are tested for a vibration level in accordance with IEC 68-2-64.*

3.3 Mounting of the compact version

The signal converter is mounted directly on the flow sensor. For installation of the flowmeter, please observe the instructions in the supplied product documentation for the flow sensor.

3.4 Mounting the field housing, remote version

Remarks for sanitary applications

- *To prevent contamination and dirt deposits behind the mounting plate, a cover plug must be installed between the wall and the mounting plate.*
- *Pipe mounting is not suitable for sanitary applications!*

Assembly materials and tools are not part of the delivery. Use the assembly materials and tools in compliance with the applicable occupational health and safety directives.

3.4.1 Pipe mounting




Figure 3-1: Pipe mounting of the field housing

- ① Fix the signal converter to the pipe.
- ② Fasten the signal converter using standard U-bolts and washers.
- ③ Tighten the nuts.

3.4.2 Wall mounting





Figure 3-2: Wall mounting of the field housing

- ① Prepare the holes with the aid of the mounting plate. For further information refer to *Mounting plate, field housing* on page 18.
- ② Fasten the mounting plate securely to the wall.
- ③ Screw the signal converter to the mounting plate with the nuts and washers.

Mounting multiple devices next to each other



$a \geq 600 \text{ mm} / 23.6''$
 $b \geq 250 \text{ mm} / 9.8''$

4.1 Safety instructions

All work on the electrical connections may only be carried out with the power disconnected. Take note of the voltage data on the nameplate!

Observe the national regulations for electrical installations!

For devices used in hazardous areas, additional safety notes apply; please refer to the Ex documentation.

Observe without fail the local occupational health and safety regulations. Any work done on the electrical components of the measuring device may only be carried out by properly trained specialists.

Look at the device nameplate to ensure that the device is delivered according to your order. Check for the correct supply voltage printed on the nameplate.

4.2 Connection diagram

The device must be grounded in accordance with regulations in order to protect personnel against electric shocks.




Figure 4-1: Connection diagram

- ① Terminal compartment for signal converter
- ② Terminal compartment for measuring sensor
- ③ Connect shielding to spring terminal (drain wire and overall shield)

| Cable | Cable | Connection terminal |
|------------|--------|---------------------|
| Cable pair | Colour | |
| 1 | yellow | X1 SA+ |
| 1 | black | X1 SA- |
| 2 | green | X1 SB+ |
| 2 | black | X1 SB- |
| 3 | blue | X2 T1 |
| 3 | black | X2 T2 |
| 4 | red | X2 T3 |
| 4 | black | X2 T4 |
| 5 | white | X3 DR+ |
| 5 | black | X3 DR- |

4.3 Grounding the flow sensor

There should be no difference in potential between the flow sensor and the housing or protective earth of the signal converter!

- The flow sensor must be properly grounded.
- The grounding cable should not transmit any interference voltages.
- Do not use the grounding cable to connect more than one device to ground.
- The flow sensors are connected to ground by means of a functional grounding conductor FE.
- In hazardous areas, grounding is used at the same time for equipotential bonding. Additional grounding instructions are provided in the supplementary "Ex documentation", which are only supplied together with hazardous area equipment.

4.4 Connecting power – all housing variants

The device must be grounded in accordance with regulations in order to protect personnel against electric shocks.

For devices used in hazardous areas, additional safety notes apply; please refer to the Ex documentation.

- The protection category depends on the housing versions (IP65...67 to IEC 529 / EN 60529 or NEMA4/4X/6).
- The housings of the devices, which are designed to protect the electronic equipment from dust and moisture, should be kept well closed at all times. Creepage distances and clearances are dimensioned to VDE 0110 and IEC 664 for pollution severity 2. Supply circuits are designed for overvoltage category III and the output circuits for overvoltage category II.
- Fuse protection ($I_N \leq 16$ A) for the infeed power circuit, as well as a separator (switch, circuit breaker) to isolate the signal converter must be provided close to the device. The separator must be marked as the separator for this device.

100...230 VAC (tolerance range: -15% / +10%)

- Note the power supply voltage and frequency (50...60 Hz) on the nameplate.
- The protective ground terminal **PE** of the power supply must be connected to the separate U-clamp terminal in the terminal compartment of the signal converter

240 VAC + 5% is included in the tolerance range.


24 VDC (tolerance range: -55% / +30%)

24 VAC/DC (tolerance range: AC: -15% / +10%; DC: -25% / +30%)

- Note the data on the nameplate!
- For measurement process reasons, a functional ground **FE** must be connected to the separate U-clamp terminal in the terminal compartment of the signal converter.
- When connecting to functional extra-low voltages, provide a facility for protective separation (PELV) (acc. to VDE 0100 / VDE 0106 and/or IEC 364 / IEC 536 or relevant national regulations).

For 24 VDC, 12 VDC - 10% is included in the tolerance range.

Power supply connection



- ① 100...230 VAC (-15% / +10%), 22 VA
- ② 24 VDC (-55% / +30%), 12 W
- ③ 24 VAC/DC (AC: -15% / +10%; DC: -25% / +30%), 22 VA or 12 W

4.5 Inputs and outputs, overview

4.5.1 Combinations of the inputs/outputs (I/Os)

This signal converter is available with various input/output combinations.

Basic version

- Has 1 current output, 1 pulse output and 2 status outputs / limit switches.
- The pulse output can be set as status output/limit switch and one of the status outputs as a control input.

Ex i version

- Depending on the task, the device can be configured with various output modules.
- Current outputs can be active or passive.
- Optionally available also with Foundation Fieldbus and Profibus PA

Modular version

- Depending on the task, the device can be configured with various output modules.

Bus systems

- The device allows intrinsically safe and non intrinsically safe bus interfaces in combination with additional modules.
- For connection and operation of bus systems, note the supplementary instructions.

Ex option

- For hazardous areas, all of the input/output variants for the housing designs C and F can be delivered with terminal compartment in Ex d (pressure-resistant casing) or Ex e (increased safety).
- For connection and operation of Ex devices, note the supplementary instructions.

4.5.2 Description of the CG number



Figure 4-2: Marking (CG number) of the electronics module and input/output variants

- ① ID number: 3
- ② ID number: 0 = standard; 9 = special
- ③ Power supply option
- ④ Display (language versions)
- ⑤ Input/output version (I/O)
- ⑥ 1st optional module for connection terminal A
- ⑦ 2nd optional module for connection terminal B

The last 3 digits of the CG number (⑤, ⑥ and ⑦) indicate the assignment of the terminal connections. Please refer to the following examples.

Examples for CG number

| | |
|---------------|--|
| CG 330 11 100 | 100...230 VAC & standard display; basic I/O: I_a or I_p & S_p/C_p & S_p & P_p/S_p |
| CG 330 11 7FK | 100...230 VAC & standard display; modular I/O: I_a & P_N/S_N and optional module P_N/S_N & C_N |
| CG 330 81 4EB | 24 VDC & standard display; modular I/O: I_a & P_a/S_a and optional module P_p/S_p & I_p |

Description of abbreviations and CG identifier for possible optional modules on terminals A and B

| Abbreviation | Identifier for CG No. | Description |
|--------------|-----------------------|---|
| I_a | A | Active current output |
| I_p | B | Passive current output |
| P_a / S_a | C | Active pulse output, frequency output, status output or limit switch (changeable) |
| P_p / S_p | E | Passive pulse output, frequency output, status output or limit switch (changeable) |
| P_N / S_N | F | Passive pulse output, frequency output, status output or limit switch acc. to NAMUR (changeable) |
| C_a | G | Active control input |
| C_p | K | Passive control input |
| C_N | H | Active control input to NAMUR Signal converter monitors cable breaks and short circuits acc. to EN 60947-5-6. Errors indicated on LC display. Error messages possible via status output. |
| - | 8 | No additional module installed |
| - | 0 | No further module possible |

4.5.3 Fixed, non-alterable input/output versions

This signal converter is available with various input/output combinations.

- The grey boxes in the tables denote unassigned or unused connection terminals.
- In the table, only the final digits of the CG no. are depicted.
- Connection terminal A+ is only operable in the basic input/output version.

| CG no. | Connection terminals | | | | | | | | |
|--------|----------------------|---|----|---|----|---|----|---|----|
| | A+ | A | A- | B | B- | C | C- | D | D- |

Basic I/Os (standard)

| | | | | | |
|-------|---------------------------------|----------------------------------|---|------------------------|---|
| 1 0 0 | | I _p + HART® passive ① | S _p / C _p passive ② | S _p passive | P _p / S _p passive ② |
| | I _a + HART® active ① | | | | |

Ex i I/Os (option)

| | | | | | |
|-------|--|------------------------|---|--------------------------------|---|
| 2 0 0 | | | | I _a + HART® active | P _N / S _N NAMUR ② |
| 3 0 0 | | | | I _p + HART® passive | P _N / S _N NAMUR ② |
| 2 1 0 | | I _a active | P _N / S _N NAMUR C _p passive ② | I _a + HART® active | P _N / S _N NAMUR ② |
| 3 1 0 | | I _a active | P _N / S _N NAMUR C _p passive ② | I _p + HART® passive | P _N / S _N NAMUR ② |
| 2 2 0 | | I _p passive | P _N / S _N NAMUR C _p passive ② | I _a + HART® active | P _N / S _N NAMUR ② |
| 3 2 0 | | I _p passive | P _N / S _N NAMUR C _p passive ② | I _p + HART® passive | P _N / S _N NAMUR ② |

PROFIBUS PA (Ex i) (option)

| | | | | | | | |
|-------|--|------------------------|---|--------------|-----|--------------|-----|
| D 0 0 | | | | PA+ | PA- | PA+ | PA- |
| | | | | FISCO Device | | FISCO Device | |
| D 1 0 | | I _a active | P _N / S _N NAMUR C _p passive ② | PA+ | PA- | PA+ | PA- |
| | | | | FISCO Device | | FISCO Device | |
| D 2 0 | | I _p passive | P _N / S _N NAMUR C _p passive ② | PA+ | PA- | PA+ | PA- |
| | | | | FISCO Device | | FISCO Device | |

FOUNDATION Fieldbus (Ex i) (option)

| | | | | | | | |
|-------|--|---------------|--------------------------------------|--------------|------|--------------|------|
| E 0 0 | | | | V/D+ | V/D- | V/D+ | V/D- |
| | | | | FISCO Device | | FISCO Device | |
| E 1 0 | | I_a active | P_N / S_N NAMUR C_p passive ② | V/D+ | V/D- | V/D+ | V/D- |
| | | | | FISCO Device | | FISCO Device | |
| E 2 0 | | I_p passive | P_N / S_N NAMUR C_p passive ② | V/D+ | V/D- | V/D+ | V/D- |
| | | | | FISCO Device | | FISCO Device | |

① Function changed by reconnecting

② Changeable

4.5.4 Alterable input/output versions

This signal converter is available with various input/output combinations.

- The grey boxes in the tables denote unassigned or unused connection terminals.
- In the table, only the final digits of the CG no. are depicted.
- Term. = (connection) terminal

| CG no. | Connection terminals | | | | | | | | |
|--------|----------------------|---|----|---|----|---|----|---|----|
| | A+ | A | A- | B | B- | C | C- | D | D- |

Modular I/Os (option)

| | | | | |
|------|--|---|--------------------------------|---|
| 4 __ | | max. 2 optional modules for term. A + B | I _a + HART® active | P _a / S _a active ① |
| 8 __ | | max. 2 optional modules for term. A + B | I _p + HART® passive | P _a / S _a active ① |
| 6 __ | | max. 2 optional modules for term. A + B | I _a + HART® active | P _p / S _p passive ① |
| B __ | | max. 2 optional modules for term. A + B | I _p + HART® passive | P _p / S _p passive ① |
| 7 __ | | max. 2 optional modules for term. A + B | I _a + HART® active | P _N / S _N NAMUR ① |
| C __ | | max. 2 optional modules for term. A + B | I _p + HART® passive | P _N / S _N NAMUR ① |

PROFIBUS PA (option)

| | | | | | | |
|------|--|---|---------|---------|---------|---------|
| D __ | | max. 2 optional modules for term. A + B | PA+ (2) | PA- (2) | PA+ (1) | PA- (1) |
|------|--|---|---------|---------|---------|---------|

FOUNDATION Fieldbus (option)

| | | | | | | |
|------|--|---|----------|----------|----------|----------|
| E __ | | max. 2 optional modules for term. A + B | V/D+ (2) | V/D- (2) | V/D+ (1) | V/D- (1) |
|------|--|---|----------|----------|----------|----------|

PROFIBUS DP (option)

| | | | | | | | | |
|------|--|-------------------------------|---------------|--------------|--------------|---------------|--------------|--------------|
| F _0 | | 1 optional module for term. A | Termination P | RxD/TxD-P(2) | RxD/TxD-N(2) | Termination N | RxD/TxD-P(1) | RxD/TxD-N(1) |
|------|--|-------------------------------|---------------|--------------|--------------|---------------|--------------|--------------|

Modbus (option)

| | | | | | | |
|--------|--|---|--|--------|--------------|--------------|
| G __ ② | | max. 2 optional modules for term. A + B | | Common | Sign. B (D1) | Sign. A (D0) |
| H __ ③ | | max. 2 optional modules for term. A + B | | Common | Sign. B (D1) | Sign. A (D0) |

① Changeable

② Not activated bus terminator

③ Activated bus terminator





The specifications contained herein are subject to change without notice and any user of said specifications should verify from the manufacture that the specifications are currently in effect. Otherwise, the manufacturer assumes no responsibility for the use of specifications which may have been changed and are no longer in effect.

GuidantMeasurement.com
© 2025 Guidant Corporation
All rights reserved.

Corporate Headquarters
5825 North Sam Parkway West
Suite 120
Houston, TX 77086 USA

USA
1602 Wagner Avenue
Erie, PA 16510 USA
+1 814.898.5000

Germany
Regentstrasse 1
25474 Ellerbek, Germany
+49 4101 304.0